


ZF = 468 / 492 kHz



Schalter	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Kurz I																
Kurz II																
Mittel																
Lang																
TA																

Radio SABA 442WLK